

Insulation Blanket Jackets

Maintenance and Operations Guidelines




The valve is designed to operate without requiring the body bolts or packing gland bolts to be retightened.

This valve will have higher than normal stem torque. The handles are designed for approximately 80 pounds of force (maximum) to rotate the valves.

No routine lubrication or maintenance is required on the valve.

Unless specifically stated, all ValvTechnologies products are designed for clockwise rotation to close and counter-clockwise to open.

Caution: Insulation must not be applied above the body flat.



The metal clips allow the blanket to securely insulate the valve even after it has been used or removed without damaging the surrounding pipe insulation.



Do not lag or insulate above this line.

